



Ideal packaging solutions for sophisticated products



MEAT AND SAUSAGE PRODUCTS





The Wipak Group helps you to develop economical and ecologically sustainable packages – and to successfully bring them on the market. Numerous innovations are the result of a close and trustful cooperation with our customers and industrial partners.

From the idea to POS – we ...

- ▶ provide support for all questions concerning **package development**
- ▶ define property profiles in cooperation with you and help you to **select the best materials**
- ▶ make sure that your **packaging ideas** can be realized under technological aspects
- ▶ provide consultation for **print image design**
- ▶ develop and test **sample packages**
- ▶ optimize **packaging processes**
- ▶ ensure that products, films and machines are **ideally adapted** to each other

IMPULSES FOR INNOVATIVE PACKAGING

State-of-the-art machines, efficient processes, sophisticated services – from pack design to printing – in-depth market know-how and global presence ensure that with our products we provide major contributions to the value added for our customers.

Which packaging concepts are most promising? And how can they be materialized both technologically and economically? What are the ecological and legal aspects to be considered? Benefit from our extensive experience, from our broad spectrum of packaging films and from our multiple refinement options.

Using our own thermoforming and flexoprinting machines we are able to implement even complex designs. Glossy or mat spot painting, metalized and demetalized films, paper and paper-like surfaces or double-printing according to samples – from print image consulting to fully automatic production of printing plates or consistent colour management, we are able to concentrate all activities under the roof of the Wipak Group. For our customers, this ensures efficient, fast and flexible implementation of their projects as well as a constantly high, reproducible quality.

Added value – our services for you:

- ▶ pack design
- ▶ film development
- ▶ laboratory services
- ▶ printing
- ▶ technical support
- ▶ training and workshops





THERMOFORMING, SEMI-RIGID AND FLEXIBLE FILMS

Wipak's composite films are exactly adapted to the product to be packaged and they can be equipped with a barrier layer if required. Our polyester-based films such as Multipet are ideally suited for semi-rigid packages with a high gas barrier. They can be provided as thermoforming rolls. Flexible films are based on a polyamide/polyolefin compound which can be combined with an outside polypropylene or paper layer if required. In addition to a lot of specialties, the Combitherm product range e.g. contains sterilizable grades.



LIDDING FILMS/ FLOWPACK FILMS

Our lidding films protect the quality and freshness of food products which are packaged under vacuum or under a modified atmosphere (MAP). Antifog, EVOH barrier or reclosing system – the type of film to be used depends on the individual requirement profile. Polypropylene, polyamid, polyester or paper composites are used according to the specific criteria of each application.

**Economical + sustainable
= ideal solutions for me**



PREPACK: PVDC-FREE

For freshly packaged meat and sausage products, Wipak has developed films that are PVDC-free. They consist, amongst others, of PET composite films or paper composites. Thanks to an EVOH barrier, these films are suitable for gassing, protecting ideal protection against oxygen.



RECLOSABLE FILMS

Wipak has a broad range of reclosable packages. One example is the booklet closure: two package halves are thermoformed with different depths, with one half being put over the tray as a lid. Multipet topforming: two polyester trays are pressed into each other and sealed hermetically. The principle of the Repak system consists of an adhesive layer in the tray film and a sealing layer with migration barrier.

e + top quality + reliable
at and sausage products



Wipak solutions on the Internet

For further product information and typical applications, please visit www.wipak.com

Benefit from our expertise!
Talk to us.

Your Partner in Packaging

CZECH REPUBLIC

Wipak Prague (Sales Office)
Tel. +420 22 05 61 644
info.czech@wipak.com

FINLAND

Wipak Oy (Manuf. Unit)
P.O. Box 45
15561 Nastola
Tel. +358 20 510 311
info.fi.wn@wipak.com

Biaxis Oy (Manuf. Unit)
Teknikonkatu 2
15520 Lahti
Tel. +358 20 510 312
info@biaxis.com

Wipak Valkeakoski Oy
(Manuf. Unit)
Kaivolankatu 5
37630 Valkeakoski
Tel. +358 20 510 311
info.fi.wv@wipak.com

FRANCE

Wipak Gryspeert SAS
(Manuf. Unit)
CS 20006
Zone des Bois
59558 Bousbecque Cédex
Tel. +33 3 20 11 56 56
info.france@wipak.com

GERMANY

Wipak Walsrode
GmbH & Co. KG (Manuf. Unit)
Postfach 1661
29656 Walsrode
Tel. +49 5161 4880 0
info.germany@wipak.com

HUNGARY

Wipak Budapest (Sales Office)
Tel. +36 12 18 51 52
info.hungary@wipak.com

ITALY

Wipak Bordi S.r.l. (Manuf. Unit)
Via Ungaretti 3
29012 Caorso
Tel. +39 523 821382
info@bordi.it

JAPAN

Wipak Ltd. Japan Branch
(Sales Office)
Tel. +81 45 67 07 031
kenji.yamajo@wipak.com

NETHERLANDS

Wipak B.V. (Manuf. Unit)
Nieuwstadterweg 17
6136 KN Sittard
Tel. +31 46 420 2999
info.benelux@wipak.com

NORWAY

Wipak Oslo (Sales Office)
Tel. +47 22 90 13 10
info.norway@wipak.com

POLAND

Wipak Polska Sp. z o.o.
(Manuf. Unit)
ul. Smaków 10
49-318 Skarbimierz Osiedle
Tel. +48 77 404 200
info.poland@wipak.com

PR CHINA

Wipak Shanghai (Sales Office)
Tel. +86 21 54 22 54 05
info.china@wipak.com
Wipak Packaging Changshu
Co., Ltd. (Manuf. Unit)
Tel. +86 512 823 659 58
Jari.tevajarvi@wipak.com

RUSSIA

Wipak OOO, Moscow
(Sales Office)
Tel. +7 49 56 47 48 03
info.russia@wipak.com

Wipak OOO, St. Petersburg
(Sales Office)
Tel. +7 81 23 36 97 49
info.russia@wipak.com

SPAIN

Wipak Ibérica 2003, SL
(Manuf. Unit)
C/Sant Celoni, nº 76, P.I.Can Prat
08450 Llinars del Vallés
Barcelona
Tel. +34 93 781 20 20
info.spain@wipak.com

SWEDEN

Wipak AB (Sales Office)
Tel. +46 40 19 16 00
info.sweden@wipak.com

SWITZERLAND

Key Customer Manager
Tel. +41 79 929 51 21
francesco.rosa@wipak.com

TURKEY

Wipak Türkiye (Sales Office)
Tel. +90 21 67 00 17 92
kayhan.kaya@wipak.com

UNITED KINGDOM

Wipak UK Ltd. (Manuf. Unit)
Buttington Business Park
Welshpool, Powys, SY21 8SL
Tel. +44 1938 555 255
info.uk@wipak.com

www.wipak.com
info@wipak.com