

PPP

Economical, Pure PP multilayer film

Ideal for:



For steam sterilizable bandages and other cotton based woundcare dressings

STERILE 

 **WIPAK**



Material Composition

- PP, co-extruded 7-layer film
- Typical thickness range: 100-200

Applications

- High performance packaging material for bandages and other cotton based woundcare dressings
- For steam sterilization
- Sealable with uncoated steam papers and polymeric top webs with PP sealing layer

Benefits

- Economical forming film for low cost medical devices
- Tear-open features with OPP 2070 in OW applications
- Non-curling due to symmetric structure
- Outstanding clarity
- Excellent mechanical strength and puncture resistance
- Very good runnability

Wipak reserves right to make changes at any time without notice.

WIPAK Oy
P.O. Box 45
Wipaktie 2
FI-15561 Nastola, Finland
Tel: +358-20510 311
Fax: +358-20510 3333
email: ind@wipak.com
www.wipak.com